

E3MAC BMS INTERFACE MODULE

The following information should be utilized when selecting the “BI” (BMS Integration) option on E3MAC inverters. For more detailed integration information consult the documentation for the BMS system or Isolite’s BMS start-up guide.



E3MAC BMS INTERFACE POINTS LIST

| POINT NAME | BACNET OBJECT TYPE | BACKNET OBJECT ID | MODBUS REGISTER |
|----------------------------|--------------------|-------------------|----------------------|
| Inverter | BI | 1 | 10001 |
| Charger | BI | 2 | 10002 |
| AC Present | BI | 3 | 10003 |
| Ready | BI | 4 | 10004 |
| Switched Load | BI | 5 | 10005 |
| Alarm Summary | BI | 6 | 10006 |
| Bypass | BI | 7 | 10007 |
| Circuit Breaker Tip | BI | 8 | 10008 |
| Startup Fault | BI | 9 | 10009 |
| Charger Fault | BI | 10 | 100010 |
| Inverter Fault | BI | 11 | 100011 |
| Input Voltage (Phase A) | AI | 1 | 30001/30002 (FLOAT) |
| Input Voltage (Phase B) | AI | 2 | 30003/30004 (FLOAT) |
| Input Voltage (Phase C) | AI | 3 | 30005/30006 (FLOAT) |
| Output Voltage (Phase A) | AI | 4 | 30007/30008 (FLOAT) |
| Output Voltage (Phase B) | AI | 5 | 30009/30010 (FLOAT) |
| Output Voltage (Phase C) | AI | 6 | 30011/30012 (FLOAT) |
| Output Current (Phase A) | AI | 7 | 30013/30014 (FLOAT) |
| Output Current (Phase B) | AI | 8 | 30015/30016 (FLOAT) |
| Output Current (Phase C) | AI | 9 | 30017/30018 (FLOAT) |
| Battery Voltage | AI | 10 | 30019/30020 (FLOAT) |
| Battery Current | AI | 11 | 30021/30022 (FLOAT) |
| Temperature | AI | 12 | 30023/30024 (FLOAT) |
| Output VA (Phase A) | AI | 13 | 30101/30102 (UINT32) |
| Output VA (Phase B) | AI | 14 | 30103/30104 (UINT32) |
| Output VA (Phase C) | AI | 15 | 30105/30106 (UINT32) |
| Battery Power | AI | 16 | 30107/30108 (UINT32) |
| System Runtime (Days) | AI | 17 | 30109/30110 (UINT32) |
| Inverter Runtime (Minutes) | AI | 18 | 30111/30112 (UINT32) |
| Inverter Runtime (Seconds) | AI | 19 | 30113/30114 (UINT32) |
| System Events | AI | 20 | 30115/30116 (UINT32) |