

# “CAUTION”

## READ THE FOLLOWING INSTRUCTION CAREFULLY BEFORE MOUNTING THE EXIT SIGN

1. Remove contents from box **BEING CAREFUL NOT TO SNAP COVER OVER THE GRAY BACKPAN.**
2. Carefully remove sign from gray backpan.
3. Attach gray backpan on the wall using appropriate flathead fasteners. The bottom of the frame should be approximately 6” from the floor.
4. Place the sign in the backpan that is now attached to the wall. If arrows are required, remove them before placing sign into backpan.
5. Snap clear plastic face onto backpan making sure the tab snap into place.

If the cover is snapped onto the backpan and for some reason has to be removed, using three allen wrenches, insert one under each of the tabs on the top and on one side. Applying upward pressure on the allen wrenches to disengage tabs, gently pull the corner of the frame that is between the allen wrench on top and the allen wrench on the side forward.